Tips for an Accurate Measurement

- Ensure the sample does not contain any debris.
- Whenever the cuvette is placed into the checker, it must be dry outside and free of fingerprints, oil and dirt.
- Wipe the cuvette thoroughly with HI731318 microfiber cleaning cloth or a lint-free cloth prior to insertion.
- Shaking the cuvette can generate bubbles, causing higher readings. To obtain accurate measurements, remove such bubbles by swirling or by gently tapping the cuvette.
- Do not let the reacted sample stand too long after reagent has been added, as accuracy will be affected.
- Discard the sample immediately after the reading has been taken or the glass might become permanently stained.



Battery Replacement

To save the battery, the checker shuts down after 10 minutes of non-use. A fresh battery lasts for a minimum of 5000 measurements. When the battery is drained, the instrument displays "bAd" then "bAt", and turns off.

To replace the battery, follow the next steps:

- 1. Press and hold the ON/OFF button to turn the checker off.
- 2. Turn the instrument upside down and use a screwdriver to unfasten the screw and remove the battery cover.



- Remove the old battery, replace it with a new 1.5V AAA battery, inserting the negative end first.
- 4. Replace the battery cover, fasten and tighten the screw.

Accessories

Reagent Sets	
HI705-25	Reagents for 25 Silica Low Range tests
Other Accessories	
HI705-11	Silica Low Range certified standard kit
HI731225	Cuvette black cap for Checker® HC colorimeters (4 pcs.)
HI731318	Cloth for wiping cuvettes (4 pcs.)
HI731321	Glass cuvette and seal cap for Checker $^{^{(\! B)}}$ HC colorimeters (4 pcs.)
HI740028P	1.5V AAA battery set (12 pcs.)
HI93703-50	Cuvette cleaning solution, 230 mL

Certification

All Hanna Instruments conform to the CE European Directives.

Disposal of Electrical & Electronic Equipment. The product should not be treated as household waste. Instead hand it over to the appropriate collection point for the recycling of electrical and electronic equipment which will conserve natural resources.



Disposal of waste batteries. This product contains batteries, do not dispose of them with other household waste. Hand them over to the appropriate collection point for recycling.



Ensuring proper product and battery disposal prevents potential negative consequences for the environment and human health. For more information, contact your city, your local household waste disposal service, the place of purchase or ao to www.hannainst.com.

Recommendations for Users

Before using this product, make sure it is entirely suitable for your specific application and for the environment in which it is used. Any variation introduced by the user to the supplied equipment may degrade the checker's performance. For your and the checker's safety do not use or store it in hazardous environments.

Warranty

H1705 Checker HC is warranted for a period of one year against defects in workmanship and materials when used for its intended purpose and maintained according to instructions. This warranty is limited to repair or replacement free of charge. Damage due to accidents, misuse, tampering or lack of prescribed maintenance is not covered. If service is required, contact your local Hanna Instruments Office. If under warranty, report the model number, date of purchase, serial number and the nature of the problem. If the repair is not covered by the warranty, you will be notified of the charges incurred. If the checker is to be returned to Hanna Instruments, first obtain a Returned Goods Authorization (RGA) number from the Technical Service department and then send it with shipping costs prepaid. When shipping any product, make sure it is properly packaged for complete protection.


Hanna Instruments reserves the right to modify the design, construction, or appearance of its products without advance notice.

INSTRUCTION MANUAL

H1705 Silica Low Range



HANNA instruments





Dear Customer,

Thank you for choosing a Hanna Instruments product. Please read this instruction manual carefully before using the Checker®HC handheld colorimeter. For more information about Hanna Instruments and our products, visit www.hannainst.com or e-mail us at sales@hannainst.com. For technical support, contact your local Hanna Instruments Office or e-mail us at tech@hannainst.com.

Preliminary Examination

Remove the Checker®HC handheld colorimeter and accessories from the packing material and examine it carefully. If you require any further information, please contact Hanna Instruments technical support team.

Each H1705 is delivered in a case with custom insert and is supplied with:

- Sample cuvette and cap (2 pcs.)
- Silica Low Range reagent starter kit (reagents for 12 tests)
- 1.5V AAA Alkaline battery (1 pc.)
- Instruction manual

Note: Save all packing material until you are sure that the Checker®HC handheld colorimeter works correctly. Any damaged or defective item must be returned in its original packing material with the supplied accessories.

General Description & Intended Use

HI705 Silica Low Range handheld checker is designed to accurately determine silica levels in aquariums or in applications such as water quality control checks.

H1705 features a single-button operation system and is easy to use.

The large LCD is easy to read and the auto shut-off feature assures the battery will not be drained

Specifications

Range	0.00 to 2.00 ppm (as SiO_2)
Resolution	0.01 ppm
Accuracy	± 0.03 ppm $\pm 5\%$ of reading @ 25 °C (77 °F)
Light source	Light Emitting Diode @ 610 nm
Light detector	Silicon photocell
Method	Adaptation of the ASTM D859 Method of Heteropoly Blue Method. The reaction between silica and reagents causes a blue tint in the sample.
Environment	0 to 50 °C (32 to 122 °F); max. 95% RH non-condensing
Battery type	1.5V AAA Alkaline
Auto shut-off	After 10 minutes of non-use
Dimensions	86.0 x 61.0 x 37.5 mm (3.4 x 2.4 x 1.5")
Weight	64 g (2.3 oz)


Functional Description & LCD Display



Measurement Procedure

- · Press the ON/OFF button to turn the checker on. All seaments will be displayed for a few seconds, followed by "Add", "C.1" with "Press" hlinking
- Fill the cuvette with 10 mL of unreacted sample. and add 6 drops of HI705A-0 Silica Low Range reagent A. Replace the cap and swirl the solution Wait 4 minutes and add the content of one packet of HI705B-O Silica Low Range reagent B. Replace the cap and shake until it is completely dissolved. Wait 1 minute. This is the blank. Insert the cuvette into the checker and close the cap
- Press the ON/OFF button. When the display shows "Add", "C.2" with "Press" blinking, the checker is zeroed
- Remove the cuvette, unscrew the cap and add the content of one packet of HI705C-0 Silica Low Range reagent. Replace the cap and shake until it is completely dissolved.
- Insert the cuvette into the checker and close the cap. Press and hold the ON/OFF button. The display will show the countdown prior to the measurement. Alternatively, wait 3 minutes and press the button.
- . When the timer ends the checker will perform the reading. The instrument displays the silica (SiO₂) concentration in mg/L (ppm). The checker automatically turns off 10 minutes after reading

Errors & Warnings



Light High: There is an excess amount of ambient light reaching the detector. Please check the preparation of the zero



Light Low: There is not enough light to perform a measuremen Please check the preparation of the zero cuvette.



Inverted Cuvettes: The sample and the zero cuvettes are inverted. Swap the cuvettes and repeat the measurement.



Under Range: A blinking "0.00" indicates that the sample absorbs less light than the zero reference. Check the measurement procedure and make sure to use the same cuvette for reference (zero) and measurement.



Over Range: Maximum concentration value displayed blinking indicates the measured value is outside the limits of the method. Verify that the sample does not contain any debris. Dilute the sample and repeat the measurement.



Battery Low: Battery level is too low for the checker to function properly. Replace the battery with a new one.



Drained Battery: The battery is drained and must be replaced Replace the battery with a new one and restart the checker.



















