



testo 330i · Flue gas measuring instrument

Startup & Safety



www.testo-international.com/330imanuals

1 Commissioning

1.1. Installing the App

A mobile terminal device (tablet or smartphone) with the Android or iOS operating system and Bluetooth® interface is required to operate the **testo 330i** measuring instrument.

The **testo 330i** App also needs to be installed on this mobile device:


1. Open the AppStore on the mobile terminal device.
2. Enter the search term **Testo AG** to start searching.
3. Select the **testo 330i** App and install.

Information on the compatibility of the App with your mobile terminal device can be found in the respective AppStore.

Observe the documentation for your mobile terminal device when installing the App!

1.2. Establishing a connection

✓ The **testo 330i** App must be installed on your mobile terminal device.

1. Switch on the measuring instrument: Press the  key.
 - Measuring instrument starts up: The blue LED flashes (0.05 s on / 0.5 s off).
 - Connecting mode is activated: The blue LED flashes (0.5 s on / 0.5 s off).
2. Start up the **testo 330i** App on your mobile terminal device.
 - The **Find Device** function is activated: Any compatible devices within radio range are displayed (product name + last 4 digits of the device serial number).
3. Tap instrument designation to select a measuring instrument.
 - It may take around 30 s to establish the connection.
 - A Bluetooth® connection is established: The blue LED is constant.
 - The first time a connection is established with a measuring instrument the **Country version** function opens.

The Country version configuration affects the measurement parameters, fuels, fuel parameters, and the basis of and formulas for calculations activated in the measurement box.

4. Tap the Country version to be activated.
5. Tap **Continue** to perform a restart.
6. Restart the **testo 330i** App.
7. Tap instrument designation to select a measuring instrument.
 - The **Flue gas** function opens.
 - The instrument is operational.

1.3. Further information



It is paramount that you read and observe the warning and safety instructions in the **Safety and the environment** section before using the measuring instrument!!

Tutorial

A description of the most important operating controls and functions can be opened in the App.

>  | **Help** | **Tutorial**

Instruction manual

For further information please download the instruction manual as a PDF file from our website: **www.testo.com/330imanuals**

The website can also be called up directly from your mobile terminal device (internet connection required):

>  | **Help** | **Help online**

2 Safety and the environment

Use

- > Please read this documentation through carefully and familiarize yourself with the product before putting it to use. Pay particular attention to the safety instructions and warning advice in order to prevent injuries and damage to the products.
- > Keep this document to hand so that you can refer to it when necessary.
- > Hand this documentation on to any subsequent users of the product.

2.1. Ensure safety

Please note for transportation and use:

Strong holding magnets on the back of the instruments!

WARNING

Magnetic field

May be harmful to those with pacemakers.

- > Keep a minimum distance of 15 cm between pacemaker and instrument.

ATTENTION

Magnetic field

Damage to other devices!

- > Keep a safe distance away from products that could be damaged by the effects of magnetism (e.g. monitors, computers or credit cards).

For differential pressure measurements please note:

WARNING

Dangerous mixture of gases

Danger of explosion!

- > Make sure there are no leaks between the sampling point and the measuring instrument.
- > Do not smoke or use naked flames during measurement.

Please note when emptying condensate:

CAUTION


Condensate entering the gas path.

Damage to sensors and flue gas pump!

- > Do not empty the condensate container while the flue gas pump is in operation.

Safety related symbols on the instrument

Representation	Explanation
----------------	-------------

Representation	Explanation
	<p>If the product is not used in strict compliance with this documentation, the intended protection may be impaired.</p> <ul style="list-style-type: none">> Operate the product only as described in this documentation.> Please consult your dealer or the manufacturer if in doubt.

Fundamental safety instructions

- > Only operate the product properly, for its intended purpose and within the parameters specified in the technical data. Do not use any force.
- > Do not operate the instrument if there are signs of damage at the housing, mains unit or feed lines.
- > Do not perform contact measurements on non-insulated, live parts.
- > Do not store the product together with solvents. Do not use any desiccants.
- > Carry out only the maintenance and repair work on this instrument that is described in the documentation. Follow the prescribed steps exactly. Use only original spare parts from Testo.
- > Any further or additional work must only be carried out by authorised personnel. Testo will otherwise refuse to accept responsibility for the proper functioning of the measuring instrument after repair and for the validity of certifications.
- > Only use the device in closed, dry rooms and protect it from rain and moisture.
- > Temperatures given on probes/sensors relate only to the measuring range of the sensors. Do not expose handles and feed lines to any temperatures in excess of 70 °C unless they are expressly permitted for higher temperatures.

- > The testo 330 must be checked before commissioning for any visible damage. Do not commission the testo 330 if there are signs of damage on the housing, mains unit or supply lines. Electrical risk.
- > Dangers may also arise from the systems being measured or the measuring environment: Note the safety regulations valid in your area when performing the measurements.

2.2. Protecting the environment

- > Dispose of faulty rechargeable batteries/spent batteries in accordance with the valid legal specifications.
- > At the end of its useful life, send the product to the separate collection for electric and electronic devices (observe local regulations) or return the product to Testo for disposal.

